

Countertop Combined Self-checkout Kiosk

KH-2100C

- 21.5" HD Touch Screen
- 10 points PCAP Touch
- Support Ethernet & WiFi
- Options: Printer, Scanner, Card Reader Holder, and Camera
- Application: Countertop



FEATURES



Card Reader Holder
(Without Card Reader)
Width range:80-135mm

Option Device: Camera



1080P HD Touch Screen
10 Points PCAP Touch



Option Device: Scanner



Space for Printer
L150×W130×H200mm
(Without Printer)



Cable Cover



VESA Standard Mounting Holes
(75×75/100×100mm)



Hole for Cable Routing



Compact Combination Efficient Checkout without Space Occupation

The countertop combined self-checkout kiosk KR-1900C, its highlight characteristics are fashion compact structure and efficient checkout without flooring space occupation. It can be easily installed, such as on the commercial display counter or checkout counter directly, and is suitable for retail shops, restaurant, and small supermarket.

The kiosk is combined with 21" HD touch screen and stand with free space for printer. Several option devices are available to meet different application requirement, including printer, scanner, camera and card reader holder.

Stable base with dual assembled panels.



HD Original Screen Multiple Points Capacitive Touch

21.5" HD original commercial screen, configured with 1920x1080 high resolution, 3000:1 ratio, and 178° viewing image, offers users comfortable visual experience.

10 point capacitive touch and 10mm fast response, support kinds of gestures by point or slide touch with fantastic checkout experience.



support kinds of
gestures by point



1080P HD original screen



178° viewing image



OS Support:
Android/Windows


Cable Hidden Routing High Security

The interior of the stand, reserving space for cable hidden routing, and has advantage of safety and neat.


The cable cover is equipped to the side of the screen, protecting the switch, interface and cables from public touch and damage.



APPLICATIONS















The convenience store



The gift shop


ASSEMBLY & INSTALLATION







Packing List

 <p>A A=1 PCS</p>	 <p>C C=2 PCS</p>	 <p>D D=8+2 PCS</p>	 <p>E E=6+2 PCS</p>	 <p>F F=6+2 PCS</p>	 <p>G G=6+2 PCS</p>	 <p>M M=2 PCS</p>
	 <p>H H=4+2 PCS</p>	 <p>I I=2+2 PCS</p>	 <p>J J=1 PCS</p>	 <p>K K=1 PCS</p>	 <p>L L=2+2 PCS</p>	

Installation Instructions


①



D ---      

J S4

②




Printer

Double-sided tape


Printer mounting option 1:
Stick on mounting plate by double-sided tape;

Printer mounting option 2:
Screw on mounting plate by self-tapping screws.

③



④



Power adapter

Monitor

VESA mounting plate
(VESA 75*75/100*100)

H

⑤

